



# Grasshopper Anti Flap Kit

Manufactured in Australia by Sunbuster Shades.

For assistance please call 0429 846 628

- Contents:**
- 1 x Grasshopper bars set (4 pieces + 2 inner pieces)
  - 12 x Grasshopper Yellow Clips
  - 1 x Fittings kit (2 x black knobs with backing plates, 2 x M6 metal screws with washers).
  - 1 x Instructions sheet

## Assembly of the bars

Place a backing plate on your finger and place upwards through the hole in the other outer bar and screw the black knob in until it just touches your finger. Repeat on the second bar.



Slide the two sections together making sure the tracks are on the same side of each bar. The two bars are a mirror image for opposite ends of the awning. When fitted the sail tracks are under the vinyl and the Yellow Clips are on the outside.

## Fitting the Anti Flap Kit to the awning

To place the anti flap bar into the awning, start low and line up the flat paddle end over the shock absorber which mounts the awning arm to the top case. Gently lift the bar and slide the paddle towards the back of the case. Once the bar is up to the vinyl loosen the black knob and extend the bar so the slot end sits over the vertical ridge on top of the awning leg bracket. Grip the inner bar with your hand and press your thumb against the outer section to wedge the anti flap bar firmly into place and tighten the black knob.



Rotate the yellow clips off one at a time starting from the bottom. Place the clip over the vinyl with the opening facing the ground and gently push downward so the clip starts to naturally rotate, continue in a rotating motion until the clip "clicks" into place. Repeat for all eight clips.





With the anti flap Kit in place you can now add walls feeding from the gap in the centre of the bar out towards each end. NOTE: Seams and tags are on the INSIDE of the shades.

